



Mini Grinder

Handle Installation

- 1. Unscrew knob on top of grinding mechanism.**
- 2. Screw handle onto top of grinding mechanism. Handle will hit larger threads when properly tightened.**
- 3. Replace knob on top of grinding mechanism.**

Grind Adjustment

For coarser grind – With handle off, remove L shaped washer, turn gear shaped nut counter clock-wise. Replace L shaped washer, making sure prong is seated in one of the ‘gears’. Replace handle.

For finer grind – same as above but turn octagon shaped nut clockwise

Make sure cap knob is tightened securely after adjusting.

Care

Keep inside of box clear of grinds. Clean with a damp cloth. Use a small brush to clear the corners.

Use only a good quality paste wax on finish (twice a year). Bees wax salad bowl finish is recommended.

Every 3 – 4 months, grind 1/4 cup of uncooked "minute rice" to keep the burrs clean.

Grinding

Some freshly roasted beans can be a little oily and tend to stick to the box. Experiment with several type beans.

Grind with a slow steady turn. Do not go too fast! It just heats and spreads the grinds! Smell it and enjoy!

This mill will not grind fine enough for espresso, but does a nice job with walnuts and peppercorns!

Warning: Small children find this neat machine super for grinding rocks, marbles, candy bars, pet turtles and small fingers! Please be careful!